


Dual devices

Dual dimmers (two loads)



Dimmers (top/bottom)

- Replacement for stacked switches
- Tap on to favorite light level; tap off
- Tap twice for full on
- Touch rocker to adjust light level
- Single-location only
- Dimmer advanced programming features available

Dual dimmer/countdown timer switch (two loads)



Dimmer (top)

- Tap on to favorite light level; tap off
- Tap twice for full on
- Touch rocker to adjust light level
- Dimmer advanced programming features available

Timer switch (bottom)

- Tap on to start timer; tap off
- Tap twice for untimed on
- Touch rocker to adjust countdown time from 5–60 minutes
- One minute warning before lights go off
- Top LED is full on with no timer action
- Single-location only
- Timer advanced programming features available

Dual dimmer/switch (two loads)



Dimmer (top)

- Replacement for stacked switches
- Tap on to favorite light level; tap off
- Tap twice for full on
- Touch rocker to adjust light level
- Dimmer advanced programming features available

Switch (bottom)

- Tap switch on/off
- Single-location only

Advanced programming features include:

Dimmer advanced programming features

- Adjusting fade on/ fade off time
- Locked preset lighting level

Timer advanced programming features

- Bypass timer option
- Locked preset lighting level

Sensor advanced programming features

- Adjust timeout duration
- Off warning feature (dimmer with occupancy and/or vacancy sensor only)
- Sensor sensitivity
- Auto-on feature (occupancy models only)

Maestro advanced programming manual (Application Note #124) is available at www.lutron.com/applicationnotes.